

DEVICE ACTUATION UNIT





Figure 4



TRAINING MODE MESSAGE TRANSMITTED FROM HAND-HELD UNIT TO DEVICE ACTUATION UNIT

HAND-HELD ID	MESSAGE LENGTH (# OF BYTES)	DEVICE ACTUATION UNIT ID	TRAINING MODE CODE	СНЕСКЅИМ
11111111	00000101	00000001	11110000	11110001
Figure 7A				170

ACKNOWLEDGEMENT MESSAGE TRANMITTED FROM DEVICE ACTUATION UNIT TO HAND-HELD UNIT AFTER DEVICE ACTUATION UNIT RECEIVES TRAINING MODE MESSAGE

HAND-HELD ID	MESSAGE LENGTH	DEVICE ACTUATION UNIT ID	DEVICE ACTUATION UNIT ID	CHECKSUM
11111111	00000101	0000001	00000001	00000010
<u>Figure 7B</u>				\ 172

DEVICE SELECTION MESSAGE TRANSMITTED FROM HAND-HELD UNIT TO FOOT-PEDAL CONTROL SYSTEM TO SELECT DEVICE


ACKNOWLEDGEMENT MESSAGE TRANSMITTED FROM FOOT PEDAL CONTROL SYSTEM TO HAND-HELD UNIT AFTER FOOT-PEDAL CONTROL SYSTEM RECEIVES DEVICE SELECTION MESSAGE


HAND-HELD ID	MESSAGE LENGTH	UNIT ID	UNIT ID	CHECKSUM	
11111111	00000100	0000001	0001 00000001		
<u>Figure 8B</u>				176	


DEVICE ACTUATION MESSAGE TRANSMITTED FROM FOOT PEDAL CONTROL SYSTEM TO DEVICE ACTUATION UNIT FOR "ON-OFF" CONTROL OF A DEVICE

DEVICE ACTUATION MESSAGE TRANSMITTED FROM FOOT PEDAL CONTROL SYSTEM TO DEVICE ACTUATION UNIT FOR VARIABLE CONTROL OF A DEVICE

		DEVICE ACTUATION	VARIABLE	COMMAND	
HAND-HELD ID	MESSAGE LENGTH	UNIT ID	ACTUATION CODE	CODE	CHECKSUM
11111111	00000110	00000001	11110000	00000001	11110010
<u>Figure 10</u>				180	













Figure 12B





11/14





DEVICE ACTUATION UNIT








Figure 18